

What is ROKU ?

Roku is a small device which you connect to your television to view an assortment of movies in the comfort of your home.

Hicksville patrons may borrow a Roku for 7 days and watch any TV series in the library's VUDU account.

Rules

- Roku sticks go out for 7 days, and are not renewable.
- There is a \$5.00 per day late fee. A \$40.00 replacement fee will be charged if all 6 components are not returned or any are lost/damaged (includes Roku stick, remote, 2-piece power cord, HDMI Extender and instructions).
- Must be returned to the Circulation Desk (No Book or Media Drop).
- Patrons cannot alter any settings (other than Network), or tamper with the Roku stick in any way. Patrons will be fined \$10 if they change any settings or remove channels on the device.
- Patrons cannot purchase movies or add any other content to the Roku.
- The Roku will be examined upon return. Charges will be added to the patron's account for any damage found.
- Patrons must be in good standing to check out a Roku stick.

Requirements

- An HDTV with HDMI port.
- High-speed wireless Internet.



HDTV + ROKU




WIFI Network



Movies & TV Series


Instructions for Intalling and Using ROKU



1

Insert Roku into an available HDMI port and set TV to that input/source. Press **Home** button on the Roku remote until the **Home** screen appears.

Use the arrows on the remote to navigate to **Settings** and then to **Network**.



3

Press the **Home** button on the Roku remote again and use the right arrow to navigate to and select the **Vudu** channel.

2

Choose **Set up new Wi-Fi connection** and sign into your Wi-Fi network.

Be sure you know any necessary password for your network.

4

Use the arrows on the remote to select **My Vudu** and then **Movies** or **TV Shows**. Arrow down to select from among the library's collection of movies. If the movie selected only has the option to **Resume** go to the **Watch List**, select the movie and choose **Start Over**.

Unfortunately you may see a message for some movies stating "Oops! This title won't play in this quality on your display due to copyright restrictions. It can be played only if your output and display support HDCP?"

In this case you can still watch the movie, just choose "watch SD"